

Residential Telephone Line

Tone Dial Phones

A tone-dial telephone is required in order to operate our voice features. The button on the back of your telephone should be switched to "MF" position for tone-dialing.

Telephone with a Recall / Flash button

If your telephone has a "Recall" or "Flash" button, pressing one of these buttons will facilitate you to operate our Call Waiting and Conference Calling features.

Telephone without a Recall / Flash button

If your telephone has no "Recall" or "Flash" button, press down the handset hook switch quickly for the same result. When you wish to end a call, just press the handset hook switch down for a longer period of time.

Feature	Activation / Registration	Cancellation
CND Per Call Blocking	133	
CND Per Call Unblocking	1357	
Block-the-Blocker		
• Prime number	*76	#76
• Duplex number	***76	**#76
Call Forwarding		
• All Calls Forwarding	*05	#05
• Line Busy Call Forwarding	*17	#17
• No Answer Call Forwarding	*19	#19
Abbreviated Dialing	*03	#03
• Short-code dialing	**+code	
Appointment Service	*02	#02
Do-Not-Disturb	*01	#01
Per Line IDD Security	*04	#04
Per Call Disable Call Waiting	#07	